KOMATSU

SHOP MANUAL

DUMP TRUCK

SERIAL NUMBERS:
930E-5 A40512 & UP

930E-5

This material is proprietary to Komatsu and is not to be reproduced, used, or disclosed except in accordance with written authorization from Komatsu.

It is our policy to improve our products whenever it is possible and practical to do so. We reserve the right to make changes or improvements at any time without incurring any obligation to install such changes on products sold previously.

Due to this continuous program of research and development, revisions may be made to this publication. It is recommended that customers contact their distributor for information on the latest revision.

Revision History

REMARK

The links and page numbers below indicate the page on which the affected topic begins, not the page on which the specific change has been made.

CEBM041301

Updated auto lube stall pressure. *Auto Lube System Checkout* on page 30-69

Updated tie rod clamp nut torque. *Toe-In Adjustment* on page 30-18 and *Tie Rod* on page 60-26

Added aftertreatment fault codes CA1695 and CA4456. *Aftertreatment System Fault Codes* on page 40-148

Updated electronic fan clutch troubleshooting. *Troubleshoot the Electronic Fan Clutch* on page 40-400

Updated special tool group. *Special Tools List* on page 50-2

Updated rear wheel brake installation procedure. *Rear Wheel Brake Installation* on page 50-161

Updated hoist control valve tie rod nut torque procedure. *Hoist Control Valve O-Ring Replacement* on page 50-210

In Section 50, added topics *Grille and Hood Assembly Removal* on page 50-299 and *Grille and Hood Assembly Installation* on page 50-300.

In Section 60, added topic and *Diesel Exhaust Fluid (DEF) Equipment De-Crystallizing Instructions* on page 60-17.

Updated HVAC electrical circuit diagram 58B-06-06830-00 to -01.

00 CONTENTS AND FOREWORD

Contents

Revision History..... iii

00 CONTENTS AND FOREWORD..... 00-1

Foreword..... 00-17
How to Read the Shop Manual..... 00-17
Safety Alert Symbol and Signal Words..... 00-18
General Precautions Common to Operation and Maintenance..... 00-19
Preparations for Safe Operation..... 00-19
Fire and Explosion Prevention..... 00-21
Precautions When Getting On or Off the Machine..... 00-24
Precautions for Cab and Working Around Machine..... 00-26
Precautions for Diesel Exhaust Fluid (DEF)..... 00-27
Operation Precautions..... 00-30
Precautions at Jobsite..... 00-30
Precautions in Starting Engine..... 00-31
Precautions During Operation..... 00-33
Maintenance Precautions..... 00-36
Precautions Before Inspection and Maintenance..... 00-36
Precautions During Inspection and Maintenance..... 00-41
Precautions for Electrical Equipment..... 00-49
Primary Causes of Wiring Harness Failure..... 00-49
Control Cabinet Capacitor Discharge..... 00-52
Hydraulic Equipment Precautions..... 00-53

01 SPECIFICATIONS..... 01-1

Specifications..... 01-2
Specifications: 930E-5..... 01-2
Recommended Fuel, Coolant, and Lubricant..... 01-3
Suspension Cylinder Oil and Nitrogen Specifications..... 01-4
Wheel Motor Oil Specifications..... 01-5

10 STRUCTURE AND FUNCTION..... 10-1

Steering System..... 10-2
Steering System Layout..... 10-2
Steering System Operation..... 10-2
Steering Bleeddown Manifold..... 10-4
Steering Control Unit..... 10-5
Steering Accumulators (Piston Type)..... 10-6
Steering/Brake Pump Operation..... 10-6
Flow Amplifier Operation..... 10-8
Hoist System..... 10-16
Hoist System Layout..... 10-16
Hoist System Operation..... 10-17
Hoist Control Valve..... 10-18
Hoist Pilot Valve..... 10-20
Brake System..... 10-21
Service Brake System Layout..... 10-21
Hydraulic Brake Cabinet Layout..... 10-22
Service Brake Operation..... 10-22
Parking Brake Operation..... 10-23
Brake Lock Operation..... 10-23

This is the sample of the manual

Click on the download link for complete manual

Download Link

Secondary Braking and Auto Apply....10-24
Electrical System, 24V....10-25
Battery Power Supply....10-25
Battery Disconnect Switches....10-26
Engine Starting System....10-27
Auxiliary Control Cabinet Components....10-28
Body-Up Switch....10-30
Hoist Limit Switch....10-31
Automatic Lubrication (Auto Lube) System....10-32
Automatic Lubrication (Auto Lube) Grease Pump and Reservoir....10-32
Automatic Lubrication (Auto Lube) System Operation....10-33
Suspensions....10-35
Engine Emissions After-Treatment System Operations....10-36

20 STANDARD VALUE TABLE....20-1
Standard Value Table....20-2

30 TEST AND ADJUST....30-1
Hydraulic Systems....30-2
Hydraulic System Checkout Procedures....30-2
Hydraulic System Checkout Sheet....30-14
Steering System Leakage Check....30-17
Toe-In Adjustment....30-18
Hoist Cylinder Leakage Test....30-19
Steering Cylinder Leakage Test....30-19
Checking the Steering/Brake Pump Control Pressures....30-20
Adjusting the Steering/Brake Pump Control Pressures....30-21
High Altitude Steering/Brake Pump Adjustment....30-23
Brake System....30-24
Brake System Checkout Procedures....30-24
Brake System Checkout Sheet....30-34
Brake System Leakage Check....30-41
Brake Piston Leakage Test....30-42
Parking Brake Piston Leakage Test....30-43
Brake Floating Seal Pressure Test....30-43
Oil Separation Seal Pressure Test (Air Pressure Method)....30-43
Oil Separation Seal Pressure Test (Oil Pressure Method)....30-44
Wet Disc Brake Bleeding Procedure....30-44
Parking Brake Bleeding Procedure....30-45
Wet Disc Brake Wear Inspection....30-46
Parking Brake Wear Inspection....30-47
Accumulators and Suspensions....30-48
Bladder Accumulator Charging Procedure....30-48
Bladder Accumulator Leakage Test....30-49
Bladder Accumulator Storage....30-50
Piston Accumulator Charging Procedure....30-51
Piston Accumulator Leakage Test....30-52
Piston Accumulator Storage....30-53
Check for Improper Suspension Charge....30-54
Suspension Oiling and Charging Procedures....30-55
Oiling and Charging Tools and Support Blocks....30-56
Nitrogen Charging Kit Installation....30-60
Nitrogen Charging Kit Removal....30-60
Front Suspension Oiling and Charging....30-61

Rear Suspension Oiling and Charging....30-64
Suspension Pressure Test....30-67
Automatic Lubrication (Auto Lube) System....30-68
Prime the Auto Lube Pump....30-68
Prime the Auto Lube Grease Lines....30-68
Auto Lube System Checkout....30-69
Adjust the Auto Lube Cycle Timing....30-70
Cab Air Conditioning....30-72
Refrigerant Leak Detection....30-73
A/C System Performance Test....30-73
Check the A/C System Oil....30-74
A/C System Flushing Procedure....30-75
Manifold Gauge Set Installation....30-76
Refrigerant: Recycled vs Reclaimed....30-77
Refrigerant Recovery Procedure....30-77
Evacuate the A/C System....30-77
Charge the A/C System....30-78
Electrical Systems....30-80
Shutdown Procedure for Drive System Service....30-80
Electrical System Checkout Procedures....30-81
Visual Checks....30-81
Resistance Checks....30-81
Voltage Checks....30-81
Truck Function Checks....30-84
Interface Module (IM) Checks....30-85
KOMTRAX Plus II Checks....30-85
Payload Meter (PLM) Checks....30-85
Drive System Checks....30-85
Engine Delayed Shutdown Smart Timer Check....30-86
Hoist Limit Switch Check....30-87
Electrical System Checkout Sheet....30-87
Interface Module 2 (IM2)....30-89
Interface Module 2 Software and Tools....30-89
Program the IM2 Controller....30-89
Interface Module 2 Checkout Procedures....30-91
Check for IM Fault Codes....30-91
Checking Digital Inputs to the IM2....30-92
Checking Analog Inputs to the IM2....30-93
Checking Serial Communication to the IM....30-94
Checking Outputs from the IM2....30-94
Interface Module 2 Checkout Sheet....30-95
Payload Meter IV....30-98
Payload Meter IV Software and Tools....30-98
Payload Meter IV System Configuration....30-98
Configuring a Static IP Address....30-98
Payload Meter IV Software Installation....30-101
Payload Meter IV Data Downloading....30-101
Payload Meter IV Checkout Procedure....30-102
Payload Meter IV Checkout Sheet....30-108
KOMTRAX Plus II....30-109
KOMTRAX Plus II Software and Tools....30-109
Komtrax Plus II Controller Ethernet Connection....30-109
KOMTRAX Plus II Configuration....30-110
GPS Connection Test....30-113
Satellite Connection Test....30-115
Komtrax Plus II System Initialization....30-118

KomVision 30-120
KomVision Setup and Calibration Requirements 30-120
KomVision Initial Setup and Checkout Procedure 30-120
KomVision Checkout Sheet 30-126
KomVision Calibration Sheets 30-128
Calibration Sheet Layout 30-128
Unfold and Fold Calibration Sheet 30-131
Calibration Sheet Placement 30-133
KomVision Camera Calibration Procedures 30-134
Automatic 6 Camera Calibration 30-134
Manual 6 Camera Calibration 30-137
1 Camera Calibration 30-139
KomVision Radar Setting Procedure 30-142
Komatsu Wireless Bridge (KWB) 30-145
Komatsu Wireless Bridge Software and Tools 30-145
Bullet Wireless Radio Configuration 30-145
Bullet Wireless Radio Installation 30-148
NanoStation Access Point Configuration 30-149
NanoStation Access Point Connection Test 30-151
Tire Monitoring System 30-153
Tire Monitoring System Software and Tools 30-153
Tire Monitoring System Software Installation 30-153
Tire Monitoring System Configuration 30-153
Connecting to the Tire Monitoring System Web Server 30-153
Configuring a Static IP Address 30-154
Tire Monitoring System Reset 30-156
Tire Monitoring System Checkout Procedure 30-156
Tire Monitoring System Checkout Sheet 30-158

40 TROUBLESHOOTING 40-1
Fuses, Diodes and Relays 40-2
Standard Truck Fault Codes 40-13
A001 40-13
A002 40-13
A003 40-14
A004 40-14
A005 40-15
A006 40-15
A007 40-16
A008 40-16
A011 40-17
A013 40-17
A014 40-18
A016 40-18
A017 40-18
A018 40-19
A019 40-19
A022 40-20
A101 40-20
A103 40-21
A104 40-22
A105 40-22
A109 40-23
A111 40-23
A115 40-24

A117....40-25
A118....40-25
A123....40-26
A124....40-27
A125....40-27
A126....40-28
A127....40-29
A128....40-29
A139....40-30
A145....40-30
A146....40-31
A152....40-32
A153....40-32
A154....40-33
A155....40-34
A158....40-35
A166....40-35
A167....40-36
A168....40-37
A169....40-37
A170....40-38
A171....40-38
A172....40-39
A173....40-39
A184....40-40
A190....40-41
A193....40-41
A194....40-42
A195....40-42
A196....40-43
A197....40-44
A198....40-44
A199....40-45
A200....40-45
A201....40-46
A202....40-46
A203....40-47
A204....40-47
A205....40-48
A206....40-48
A207....40-49
A213....40-50
A214....40-51
A215....40-52
A216....40-53
A223....40-53
A230....40-54
A231....40-55
A233....40-56
A235....40-57
A236....40-58
A237....40-59
A240....40-59
A242....40-60
A243....40-61
A244....40-61

A245 40-62
A246 40-63
A247 40-63
A248 40-64
A249 40-64
A250 40-65
A251 40-66
A252 40-67
A253 40-68
A256 40-68
A257 40-69
A258 40-70
A260 40-70
A261 40-71
A262 40-72
A264 40-73
A265 40-74
A266 40-74
A267 40-75
A268 40-76
A270 40-76
A272 40-77
A273 40-79
A274 40-79
A275 40-80
A277 40-81
A278 40-82
A279 40-83
A280 40-83
A281 40-84
A282 40-85
A283 40-85
A284 40-87
A285 40-87
A286 40-88
A292 40-89
A303 40-90
A304 40-91
A305 40-92
A307 40-92
A309 40-93
A310 40-94
A311 40-95
A312 40-96
A313 40-97
A315 40-97
A316 40-98
A317 40-99
A318 40-101
A328 40-101
A332 40-102
A333 40-102
A334 40-103
A335 40-104
A337 40-104
A338 40-105

A339..... 40-105
A340..... 40-106
A341..... 40-106
A342..... 40-107
A343..... 40-108
A344..... 40-108
A345..... 40-109
A346..... 40-109
A347..... 40-110
A348..... 40-111
A349..... 40-111
A350..... 40-112
A351..... 40-112
A352..... 40-113
A353..... 40-114
A354..... 40-115
A355..... 40-115
A356..... 40-116
A357..... 40-116
A358..... 40-117
A359..... 40-118
A360..... 40-119
A361..... 40-120
A362..... 40-120
A363..... 40-121
A364..... 40-122
A365..... 40-122
A366..... 40-123
A400..... 40-123
A401..... 40-124
A402..... 40-125
A403..... 40-125
A404..... 40-126
A405..... 40-126
A406..... 40-126
A407..... 40-127
A408..... 40-127
A409..... 40-128
A410..... 40-129
A411..... 40-129
A412..... 40-130
A413..... 40-130
A414..... 40-130
A415..... 40-131
A416..... 40-131
A417..... 40-132
A418..... 40-133
A419..... 40-133
A420..... 40-134
A421..... 40-134
A422..... 40-134
A423..... 40-135
A424..... 40-135
A425..... 40-136
A426..... 40-137
A427..... 40-137

A428 40-138
A429 40-138
A430 40-138
A431 40-139
A432 40-139
A433 40-140
A434 40-141
A435 40-141
A436 40-142
A437 40-142
A438 40-142
A439 40-143
A440 40-143
A441 40-144
A442 40-145
A443 40-145
A444 40-146
A445 40-146
A446 40-146
A447 40-147
Aftertreatment System Fault Codes 40-148
CA256 40-148
CA1677 40-149
CA1678 40-151
CA1682 40-154
CA1683 40-162
CA1684 40-165
CA1685 40-166
CA1686 40-167
CA1695 40-168
CA1712 40-169
CA1713 40-170
CA1714 40-171
CA1715 40-172
CA1887 40-173
CA2771 40-173
CA3142 40-177
CA3143 40-178
CA3146 40-179
CA3147 40-180
CA3232 40-181
CA3497 40-184
CA3498 40-185
CA3547 40-186
CA3558 40-186
CA3559 40-188
CA3562 40-190
CA3563 40-191
CA3567 40-193
CA3571 40-195
CA3572 40-197
CA3573 40-200
CA3574 40-201
CA3575 40-202
CA3712 40-204
CA3713 40-205

CA3714....40-207
CA3867....40-208
CA3868....40-209
CA3878....40-212
CA3988....40-212
CA3995....40-216
CA4113....40-217
CA4114....40-218
CA4119....40-219
CA4121....40-219
CA4152....40-220
CA4164....40-223
CA4165....40-224
CA4166....40-227
CA4168....40-228
CA4169....40-230
CA4174....40-231
CA4175....40-233
CA4233....40-235
CA4234....40-236
CA4243....40-237
CA4277....40-238
CA4456....40-239
CA4457....40-247
CA4458....40-249
CA4459....40-251
CA4461....40-253
CA4462....40-254
CA4464....40-256
CA4465....40-259
CA4466....40-261
CA4467....40-269
CA4474....40-270
CA4475....40-272
CA4572....40-274
CA4677....40-279
CA4679....40-284
CA4682....40-285
CA4731....40-286
CA4732....40-286
CA4736....40-287
CA4737....40-288
CA4738....40-288
CA4739....40-289
CA4745....40-289
CA4768....40-290
CA4769....40-291
CA4842....40-292
CA4863....40-292
CA5115....40-293
CA5116....40-295
CA5117....40-298
CA5247....40-300
CA5653....40-301
CA5654....40-303
CA5725....40-304

CA5727....40-309
CA5728....40-312
CA5729....40-314
CA5748....40-315
CA5749....40-317
CA5751....40-319
CA5753....40-321
CA5755....40-324
CA5756....40-329
CA5758....40-331
CA5768....40-332
CA5769....40-334
CA5771....40-336
CA5772....40-338
CA5773....40-340
CA5774....40-343
CA5775....40-345
CA5776....40-351
CA5778....40-353
CA5779....40-354
CA5887....40-356
CA5888....40-357
CA5889....40-357
CA5891....40-358
CA5892....40-358
CA5893....40-359
CA6692....40-360
CA6693....40-360
CA6694....40-361
CA6695....40-362
CA6696....40-363
CA6697....40-364
CA6855....40-365
CA6856....40-367
KomVision Fault Codes....40-369
Troubleshoot the Steering System....40-380
Steering System Troubleshooting Guide....40-380
Basic Hydraulic System Checks....40-381
Steering/Brake Pump Troubleshooting Guide....40-382
Steering/Brake Pump Troubleshooting Checks....40-386
Steering/Brake Pump Fails to Unload....40-386
Steering/Brake Pump Fails to Develop Pressure....40-386
Steering/Brake Pump Slow to Develop Pressure....40-387
Steering/Brake Pump Control Valve Inspection....40-388
Steering/Brake Pump Case Drain Check....40-389
Troubleshoot the Auto Lube System....40-390
Troubleshoot the HVAC System....40-394
Control Panel Configurations....40-394
Diagnostics Mode....40-395
Error Codes....40-395
Advanced Diagnostics....40-395
Firmware Version....40-396
Additional HVAC Troubleshooting Chart....40-396
Voltage Levels....40-398
Troubleshoot the Electronic Fan Clutch....40-400

This is the sample of the manual

Click on the download link for complete manual

Download Link